


EOS Herkules S25 | S25 Vapor

Sauna heater



Installation and operating instruction

Made in Germany

CE UK CA EAC IPx4

Print no. 2902 3733 en / 06.26
Subject to technical changes

Contents

1. General safety instructions.....	4-9
2. Identification	10
▪ Manufacturer, copyright, identification, nameplate	10
▪ Intended use	11
▪ Foreseeable misuse	11
▪ General instructions	12
3. Scope of delivery	13
▪ Accessories (optional).....	13
4. Technical data	14
5. Electrical installation	15
▪ Heating period limitation.....	15
▪ Connection Herkules S25 7,5-9,0 kW - 400 V.....	16
▪ Connection Herkules S25 Vapor 7,5-9 kW - 400 V.....	17
▪ Connection 7,5-9,0 kW - 230 V	18
▪ Connection Vapor 7,5-9,0 kW - 230 V	19
▪ Internal wiring	20
▪ Vaporiser circuit diagrams.....	20
▪ Establishing an electrical connection	21
6. Installation	22
▪ Specifications for the cabin	22
▪ Dimensions and safety gaps.....	23
▪ Air inlets and outlets	24
▪ Requirements for control unit and Temperature sensor.....	25
▪ Mounting the heater	25
▪ Permanent water connection (optional).....	25
▪ Connecting the cables.....	26
▪ Filling with stones	26
7. Commissioning and operation.....	27
▪ Starting the heater.....	27
▪ Remote switching	28
▪ Water splash	28
▪ Using the vaporiser (humid sauna mode)	29
▪ Finnish sauna	31
8. Maintenance.....	32
▪ Cleaning.....	32
▪ Sauna stones	33

9. Service	34
▪ Replacing the tubular heating element	34
▪ Troubleshooting	37
10. Recycling and service address.....	38
11. General terms and conditions of service	39

1. General safety instructions

Safety levels

Safety instructions and important operating instructions are classified. Please familiarise yourself with the following terms and symbols:

WARNING

Warning

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

Caution

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

Notice

Indicates a hazardous situation which, if not avoided, will result in damage to the unit.

1.1 Mounting and electrical installation



These installation instructions are intended for qualified personnel familiar with the laws and regulations applicable to electrical installations at the installation site. Observe the following general safety instructions during mounting, configuration and commissioning of the product.

► Risk to life and limb and risk of fire

Risk to life and limb from electric shock and fire in the event of improper or faulty electrical connection. This risk remains also after completion of the installation work.

- The electrical installation of the heater, relay boxes and other electrical systems or equipment with a fixed mains connection must only be performed by a trained electrician from an authorised electrical company.
- Ensure compliance with the locally applicable standards and regulations for electrical installation.
- The system must be completely disconnected from the mains supply before commencing installation and repair work.
- The housing cover must only be removed by a specialist.

► Fire hazard from overheating

Insufficient ventilation can lead to device overheating and fire.

- Install air inlets and outlets in the cabin.
- Observe the cabin manufacturer's safety and installation instructions.

► Risk of fire due to sauna stones

It is possible for hot stones or stone pieces to fall out of the rock store.

- The sauna heater may not be placed on a floor made of easily flammable material (e.g. laminate or synthetic flooring). Ceramic tiles are recommended as a flooring option.

► Risk of burns from hot glass

Glass surfaces in the cabin become hot while the sauna is in operation.

- When installing the cabin, ensure that the touchable glass surfaces on the outside of the cabin may reach a maximum temperature of 76°C. Appropriate protection may need to be installed if required.

► Risk of burns from hot unit

During operation, the sauna heater may become hot and, if touched, could cause burns.

- Maintain a safe distance.

► Sauna cabin and sauna heater

The sauna cabin must be constructed with proper material and built in a professional manner, and the output of the sauna heater must be suited for the cabin.

- The sauna heater may only be used in sauna cabins made of suitable, low-resin and untreated material (e.g. Nordic spruce). The control unit must not be used in the cabin.
- Multiple heaters may be installed in one sauna if the heater output can properly supply the cabin volume. In this case, depending on the position, an additional safety temperature limiter must be installed for each additional heater.
- The sauna heater is not designed to be installed or set up in an alcove or under a bench or sloping roof unless the sauna heater is specifically designed and approved for this type of installation.
- Receptacles may not be installed inside the sauna cabin.
- Each sauna cabin must have air inlets and outlets. The air inlets and outlets may be installed from below or from behind the heater. The minimum dimensions of the air inlets and outlets can be found here: Technical data, Air inlets and outlets,
- The air outlet is always installed in the lower part of the wall, diagonal to the sauna heater. The air inlets and outlets must not be closed. Please observe the instructions provided by your sauna cabin manufacturer.

- Use one of the control units listed below to check and control the sauna heater. This control unit is fixed to a suitable location on the cabin's external wall, and the corresponding temperature sensor according to the installation instructions that accompany the control units inside the sauna cabin.
- The cabin lighting must be safe for sauna cabin use and installed in such a way that it can be used safely in a sauna cabin. Ensure that the heater is installed in compliance with the standards and legal norms valid in your country.
- The cabin door must open outward and must not have a lock that cannot be opened in the case of failure. We recommend magnetic or spring locks.
- All electrical installations and equipment in a sauna must comply with the IEC 60364-7-703 (DIN VDE 0100-703) norm.

1.2 Operator instruction

The operator of the sauna cabin must be instructed in the general safety instructions during commissioning. The operator must be given a copy of the operating instructions.

► Risk of electric shock

A risk to life and limb from electric shock and fire arises in the event of improper repair work. This risk remains also after work is completed.

- The housing cover must only be removed by a specialist.
- Repairs and installations must only be performed by a trained specialist.
- The system must be disconnected and removed entirely from the mains supply before commencing repair work.
- Use only original spare parts from the manufacturer.

► Fire hazard



Objects placed on the heater or protective guards can easily be ignited and cause fires.

- Attach the heater guard rail.
- Do not place objects on the heater.
- Fill the stone grate as directed.
- Inspect the sauna cabin prior to each commissioning.
- If you switch on the heater using pre-set timers or a remote control, attach a protective cover to the heater or install a suitable safety system.

► Health risks

Spending time in a sauna cabin can lead to serious health risks or even death for persons with health impairments.

- Persons with health impairments who spend time in a sauna must consult a doctor before entering a sauna cabin.

► Damage to health

Excessive time spent in a heated sauna cabin can lead to overheating of the body (hyperthermia), which may cause serious health problems and even death. Hyperthermia occurs when the core temperature of the body exceeds the norm by a few degrees.

Symptoms of hyperthermia include fever, dizziness, lethargy, sleepiness, and fainting. Side effects of hyperthermia include perception disorders, inability to recognize the need to leave the room, inability to identify imminent danger, harm to the foetus in the case of pregnant women, inability to physically leave the room and unconsciousness.

Alcohol, drugs, and medications increase the risk of hyperthermia.

- Do not exceed the maximum recommended time in the sauna.
- Leave the sauna cabin if your body responds abnormally to the heat or if you do not feel well.
- Avoid alcohol, drugs, and medications when you are using the sauna.

► Operation by children or persons with reduced mental capacity

This unit should not be used by children or persons with reduced mental capacity or limited physical or sensory abilities. Children must not play with the unit.

- Children or persons with reduced mental capacity, or limited physical or sensory abilities must be supervised to ensure they do not play with the unit.
- Children under 8 years of age should not operate the sauna cabin.
- The settings for the heating time must only be changed by children under 8 years of age if they are supervised by an adult.
- The sauna cabin must only be used by persons with reduced mental capacity, or limited physical or sensory abilities under supervision or if they have been previously instructed in its use and understand the risks.
- Children and persons who have not received proper instruction must not clean or service the system.

1.3 Standards and regulations

For an overview of the standards that were observed during design and construction of the sauna heaters, please refer to the individual product's technical data sheet that can be downloaded from www.eos-sauna.com.

2. Identification

2.1 Manufacturer

EOS Saunatechnik GmbH

Schneiderstriesch 1

D-35759 Driedorf

Tel.: +49 2775 82-0

Email: info@eos-sauna.com

2.2 Copyright

Copyright for these installation instructions remains with EOS Saunatechnik GmbH.

Copyright as per DIN ISO 16016:

The copying and distribution of this document, as well as the use and communication of its contents without express authorisation, are not permitted. Compensation will be claimed in the event of infringements. All rights reserved with regard to patent claims or submission of design or utility patent.


2.3 Identification

EOS Herkules S25/ S25 vapor is an electric sauna heater for den Finnish / Bi-O operation, and is available in a variety of output capacities.

The heater must be operated with one of the following control units, which are specified in Technical Data of this manual. The control unit is not included in the scope of delivery.

2.4 Nameplate

The nameplate is attached on the rear side of the heater.



- A. General name
- B. Model name
- C. Item number
- D. Electrical connection
- E. Approval symbols
- F. Country of origin
- G. Manufacturer
- H. Date of production
- I. Serial number

2.5 Intended use

This sauna heater is intended solely for the purpose of heating sauna cabins, together with a suitable control unit and one relay box.

EOS Herkules S25 | S25 Vapor is a floor-standing sauna heater. It is suitable for cabins for commercial and private use.



The heater is not suitable for outdoor use.

It must be operated only in sauna cabins and may not be exposed to environmental conditions such as extreme humidity and moisture or the possible formation of condensation or corrosive substances in the ambient air, as well as other weather conditions.

Any use beyond this is considered improper use. Proper use also includes compliance with operating, maintenance and servicing requirements. The manufacturer is not responsible for unauthorised modifications and damages resulting from these modifications; the person modifying the equipment alone shall bear the associated risk.

2.6 Foreseeable misuse

The following are considered instances of foreseeable misuse:

- The unit is operated without knowledge of or compliance with the safety instructions.
- Operating, service and maintenance requirements are not observed.
- The unit is operated by children under 8 years of age.
- The unit is operated by children 8 years of age or older, or persons with reduced mental capacity who have not been thoroughly instructed in its use.
- The unit is operated without sauna stones or with a rock store that is not filled as directed.
- The heater output does not match the cabin volume.
- The unit is operated with insufficient air supply or exhaust air.

2.7 General instructions

- Please note that an optimal sauna climate can be achieved only if the cabin with its air inlets and outlets, the sauna heater, and the control unit suit each other.
- Observe the specifications and information provided by your sauna retailer.
- Please note that the highest temperatures in the cabin are always above the sauna heater and that is where the temperature sensor and safety temperature limiter should be mounted according to the installation instructions for the control units.
- The sauna heaters heat the sauna cabin with heated convection air. Fresh air is drawn in through the air inlet. It is warmed and rises (convection) and is then circulated in the cabin. Some of the used air is pushed out of the cabin through the cabin's air outlet. This creates a typical sauna climate in your sauna.
Note that there is a drop in temperature from the ceiling to the floor of the sauna cabin. Temperatures are measured and regulated based on the ceiling values. Thermometers placed below the ceiling will therefore display lower temperatures. When the max. temperature is set for the area around the upper sauna bench, the bathing temperature is typically between 80°C and 90°C.
- The first time the cabin is heated, you may notice a slight odour resulting from the evaporation of consumables used in the manufacturing processes. Air out your cabin once it has been heated and before using the sauna.


3. Scope of delivery

Check the delivery to ensure that all components were delivered and that the unit is in proper working order. Contact your distributor if components are missing or damaged. The unit must not be operated if components are missing or damaged.



The following parts are included in the scope of delivery:

- 1 Sauna heater
- 1 Evaporator dish (Vapor)
- 1 Installation and Operating Instructions

Herkules S25



Herkules S25 Vapor



► Accessories (optional)

Description	Item number	Item number (Vapor)
Brackets for guard rail without wooden parts, steel	94 7308	
Brackets for guard rail without wooden parts, black	94 7589	
Guard rail with brackets	94 4468	94 4469
Rear wall cover panel stainless steel	94 5277	94 5278
Rear wall cover panel black	94 7241	94 7242

4. Technical Data

Heater power as per DIN	7,5 kW	9,0 kW
Vaporiser output/volume	*2 kW (ca. 5 l)	
Electrical connection	400 V 3N ~ 50/60 Hz	
For sauna volume	8 - 12 m ³	10 - 14 m ³
Minimum size of air inlet and outlet	35 x 5 cm	35 x 6 cm
Weight, without stones and packaging	ca. 25,5 kg ca. *30 kg	
Gerätemaße HxBxT	85 x 51 x 53 cm *85 x 83 x 53 cm	
Stone volume (not included)	ca. 25 kg, calibre 50-100 mm	
Powe extension box (PEB)	no	
For use with the sauna control units	EOS Econ-, Compact-, EmoTec-, EmoStyle-, EmoTouch-, U-Command-series	
Leakage current	max. 0.75 mA per kW heater output	
Intended use / area of application	Use in private sauna cabins	
Fuse protection for control unit	3 x 16 A	
Connection mains – control unit	5 x 2,5 mm ²	
Connection control unit – heater	5 x 1,5 mm ²	
Connection control unit – vaporizer	*4 x 1.5 mm ²	

All line cross-section specifications are the minimum cross-sections for the copper line.

* Vapor

5. Electrical installation

This chapter describes how EOS Herkules S25 | S25 Vapor is connected to the power extension units..

5.1 General instructions for electrical installation

Ensure that electrical installation is performed in compliance with the standards and legal norms valid in your country.

Following norms must be observed by the installation of sauna heating appliances:
IEC 60364-7-703 bzw. DIN VDE 0100 Teil 703

This standard states in its current edition under amendments paragraph 703.412.05 as follows:

“The additional protection must be provided for all current circuits of the sauna by one or more fault current protection devices (RCDs) with a rated differential current not exceeding 30 mA, except for sauna heaters.”

If a residual current device (RCD) is installed, ensure that there are no other electrical consumers not belonging to the sauna system which are fused via this RCD.

If the sauna heater has not been used for an extended period of time, the heater may draw moisture from the ambient air, in rare cases, could lead to the RCD to be tripped. This is a physical process and not a fault on the part of the manufacturer.

In this case, the heater must be heated by a technician under supervision which will bypass the RCD function. Once the moisture has escaped from the heating elements after approx. 10 minutes, the RCD can be integrated again in the electric circuit.

If the sauna heater will not be used for an extended period of time, we recommend that you switch on the heater every 6 weeks so that the heating elements do not accumulate moisture. If, during commissioning, the RCD is tripped, the electrical installation must be checked again.

The electrician is responsible for properly connecting the heaters; thus, the manufacturer does not assume liability.


5.2 Heating period limitation

All sauna heaters, except for those installed in public saunas, and which must be operated under the supervision of personnel, must be equipped with a timer that complies with IEC and EN standards. For safety reasons, this timer limits the operation time. This timer is typically integrated in all EOS sauna control units.


- The operation time of a public sauna must be limited so that the heating elements are without power for a minimum of 6 consecutive hours within a 24-hour period before an independent restart can take place.
- Units used in private saunas must be limited to an operating time of 6 hours, and an automatic restart is not permitted.

5.3 Connection 4,5-9,0 kW – 400 V 3N ~

► Connection overview




► Connection diagram




5.4 Connection Herkules S25 Vapor - 7,5 / 9 kW - 400 V 3N~


► Connection overview



► Connection diagram



5.5 Connection 7,5–9,0 kW at 230 V 1N ~




The cable cross sections must suit the heater power: 7.5 - 9.0 kW - 6 mm²

⚠ WARNING

Risk of fire by incorrect installation and connection

- The control unit and the sauna heater must be suitable for connection to 230 V 1N ~.
- Use suitable fuses and cable lines.

5.6 Electrical connection 7.5-9.0 kW at 230 V 1N ~



* The cable cross sections must suit the heater power: 7.5 - 9.0 kW - 6 mm²


⚠ WARNING

Risk of fire by incorrect installation and connection

- The control unit and the sauna heater must be suitable for connection to 230 V 1N ~.
- Use suitable fuses and cable lines.


5.7 Internal wiring

► 7,5 kW heater output



7,5 kW = 5x 1500 W

► 9 kW heater output




9,0 kW = 6x 1500 W

5.8 Vaporiser circuit diagrams

The vaporiser must be connected as shown in the circuit diagrams.

Please observe the installation and operating instructions for the control unit and relay boxes.



- A. Heating element
- B. Signal
- C. Thermostat
- D. Connection for sauna control unit

5.9 Establishing an electrical connection

The connection is made via terminals in the junction box on the back of the heater.

1. **WARNING!** If maintenance work is carried out on the heating register while the heater is connected to the mains, this can lead to an electric shock. Ensure that the heater and all supply lines are de-energised.
 - a) Switch off the heater.
 - b) Switch off the fuses to disconnect the heater from the power supply.
2. Remove the stones from the stone basket, lift the heater slightly and turn it so that the rear wall is freely accessible.

CAUTION! The stones may be hot! Allow the stones to cool down before you start removing them.

► Opening the junction box

1. Loosen two fastening screws on both covers of the connection box and remove the cover.


NOTE! It is essential that you follow the wiring diagram which is fixed inside the junction box of the sauna heater!

► Connecting the connection cables

1. Feed the connection cables through the cable glands into the junction box.
2. Attach wire end ferrules to the cable ends.
3. Connect the neutral wire to the supply terminals of the "N" busbars; connect the phases to the supply terminals for the three phases. Tightening torque 2.5 - 3 Nm.

► Close the junction box

1. Replace the junction box lid.
2. Screw in and tighten the four fixing screws.



6. Installation

This chapter describes how to install the sauna heater. Prior to installing the heater, air inlets and outlets must be installed in the cabin. It may be necessary to mount additional fans in the inlets/outlets. All protective films must be removed.

NOTICE

Damage due to incorrect mounting location

The heater is not suitable for outdoor use.

- The heater must be operated only inside buildings and may not be exposed to environmental conditions such as extreme humidity and moisture or the possible formation of condensation or corrosive substances in the ambient air, as well as other weather conditions.
- The heater is not designed to be installed or set up in an alcove or under a bench or sloping roof.

6.1 Requirements for the sauna cabin

The cabin must be planned and installed according to specifications before the heater is installed.

All electrical installations laid inside the cabin must be suitable for a temperature of at least 170°C.

All lines must be routed in such a way that they are well-protected, e.g. in a cable duct. If single-core lines are used as connecting cables, they must be protected by a flexible metal hose that is connected to the protective conductor.




In general, it should be noted that the sauna heater must not be set on a floor made of highly flammable material such as laminate, flooring made of plastic material, etc. Ceramic tiles are recommended as a flooring option. Floor heating in the sauna cabin increases the temperature of the floor's surface temperature.

► Installation site

The sauna heaters output selected must be appropriate for the cabin volume; see 4. Technical data

- Ceiling height of at least **1,90 m**
- When you are assembling the sauna heater you must ensure that the vertical distance between the top edge of the sauna heater and the sauna ceiling is at least **105 cm** and that the horizontal (at the side) distance between the heater and cabin wall is at least **4 cm**
- Distance heater – bench min. **4 cm**
- A heater guard rail can be mounted around the upper edge of the heater. It prevents accidental contact with hot parts of the heater.

► Dimensions and safety gaps



- A. Cabin ceiling
- B. Cabin wall
- C. Sauna heater

- D. Air inlet
- E. Heater guard rail
- F. Vaporizer tray (Vapor)

► Optional accessories:

The heater guard rail is not included and can be ordered separately as an optional accessor (see Scope of Delivery).

Its installation is described in a separate manual.

6.2 Air inlets and outlets

WARNING

Fire hazard from overheating

The heater can overheat if the air supply is insufficient. There is a risk of death due to fire.

- Ensure that the air inlets and outlets provide sufficient ventilation. Install a fan if necessary.
- Commission the cabin only after all air inlets and outlets have been opened.

NOTICE

Heating process delayed

If the heating process takes a long time, the underlying reason is that the heater receives insufficient air.

- A minimum of 5 times the cabin volume of air per hour must be exchanged.

Air inlets and outlets must be installed in the cabin to ensure a sufficient air flow in the cabin and to prevent the heater from overheating.

The required size of the air inlets and outlets depends on the heater output; see 2.4 Technical data

Depending on the location of the heater, the air inlet must be installed behind or below the heater.

- Heaters stands directly in front of the sauna wall,
- Heater is located in the middle of the cabin or in front of a glass wall.

► Wall-hanging mounting (for „W“ models only)

The air inlet must meet the following criteria:

- Location: Behind the heater,
- Height: 10 cm above the cabin floor

If there is still not enough fresh air to reach the heater, a fan must be installed at the opening outside of the cabin.

The cold air supply can be made as one bigger or several smaller openings.

► Heater is located in the middle of the cabin or in front of a glass wall

The air inlet must meet the following criteria:

- Location: Below the heater
- A duct directs fresh air to the opening or openings.
- A fan must be mounted at the beginning of the duct outside of the cabin.

6.3 Specifications for the control unit

Observe the operating conditions for the control unit to ensure that the sauna cabin's temperature control works properly. The installation site must be selected accordingly. Specifications can be found in the installation instructions for the control unit or in the instructions provided by the manufacturer of the control unit.

6.4 Installing the temperature sensor in the cabin

The temperature sensor should be mounted on the sauna ceiling as indication in the drawing in the chapter 6.1. The connection of the sensor is described in the installation manual of the sauna control unit.

6.5 Mounting the heater

The heater is supplied mounted and packaged on a pallet.

Once the cabin is ready, the heater shall be placed on a pre-defined installation place. Fill the sauna stones only after the heater has been connected and installed at its final place.

Two people are required to carry the heater.

6.6 Permanent water connection (optional)

For a permanent water supply and automatic refilling of the vaporizer tank, a special top-up device FWA01 Compact can be installed (optionally available, product code 944845). For installation details and instruction please refer to the installation manual supplied with this system.

6.7 Connecting cable lines

The connection is made via terminals in the terminal compartments on the back of the heater.


1. Remove the cover panels of the terminal compartments (heater and vaporizer). See also the section 5.6 "Making the electrical connection".
2. Connect the lines to the heater and to the vaporizer section according to the circuit diagram. A circuit diagram is attached to the inside of the terminal cover panel (heater).
3. Connect the lines to the control unit. Observe the local legal requirements, standards and norms for electric connections and installations.
4. Mount back the terminal cover panels and secure them with two screws respectively.
5. Screw in and tighten the 2 fixing screws.

6.8 Filling rock store with stones

The heater is intended for use with natural stones. Use only classic sauna stones in the prescribed size (see Technical Data) into the rock store.

Only insert the stones when the heater is in its final position.

1. Wash the stones under running water.
2. **WARNING!** Sauna stones that are stacked too tightly obstruct the flow of air. The heater could overheat. Place the stones loosely.
3. Fill the stones into the rock store up to the top edge. Leave sufficient space between stones. NOTE: For sauna heaters with contact between heating elements and sauna stones, place the stones in such a way that they do not exert excessive pressure on the heating elements.



7. Commissioning

Before the heater can be commissioned (switched on), it must be filled with sauna stones, which are available as optional accessories.

Before switching it on, ensure that the air inlets are free of lint. Remove any lint with a moist towel.

The heater is switched and controlled via the control unit. A power extension unit (PEB), if available, will be switched together with the sauna control unit.

WARNING

Fire hazard



Objects placed on the heater could catch fire. Herbs or similar substances used for aroma infusion purposes, which are located near the heater, could catch fire.

- Inspect the cabin prior to each use.
- Commission the cabin only after all air inlets and outlets have been opened.

WARNING

Fire hazard from overheating

Operating the heater without stones could cause fire or damage to the heater. Stones that are positioned too close together in the heater prevent hot air from being exhausted. This leads to overheating of the heater.

- Start the heater only if it has been filled with stones.
- Refer to the chapter Installation, section "Filling the stones".

7.1 Starting the heater

A slight odour may occur the first time the cabin is switched on because the heating elements get heated for the first time. The odour ceases upon continued operation of the heater.

► Switching the sauna heater

1. Use the control unit to select a suitable program.
2. Switch the heater on or off through the sauna control unit.

7.2 Remote switching

If you switch on the heater using the remote control, ensure that no objects are placed on the heater. A suitable safety system, for example EOSafe D/L, can be used to prevent this.

7.3 Water splash

Before the first water splash can begin, the cabin must be sufficiently heated. The temperature in the cabin is controlled from the control unit via the temperature sensor. The control panel indicates when the desired temperature has been reached.

WARNING

Fire hazard and device damage

Incorrectly diluted sauna essences, essential oils or herbs can catch fire.

- When preparing the water for a splash, follow the instructions regarding quantity as specified on the sauna essence packaging.
- Never add more sauna essence or essential oils to the infusion water than the amount indicated by the manufacturer.
- Don't use chlorinated or salty water (e.g. seawater or salty fragrances). Don't use any corrosive additives.
- Do not add herbs to the water or on the stones.
- Pour the water over the stones only.

Pour the water slowly and evenly over the stones.

As the hot air rises, steam is distributed evenly in the cabin to create a pleasant infusion experience. Please note that the sauna stones must be reheated after each water splash to generate an intense burst of steam.

After each water splash, wait approx. 10 minutes before starting the next one. This time is needed for the sauna stones to reheat.

Recommendation: During a water splash, no more than approx. 100 ml of water per m³ cabin volume should be vaporised.

7.4 Using the vaporiser (humid sauna mode)

⚠ CAUTION

Risk of scalding from hot steam

Hot steam will rise from the vaporizer while it is in use.


- Be aware of hot steam rising above the sauna heater.
- Always use a suitable container when filling the vaporizer and pay attention to the correct volume of water.
- By topping up in use ensure a proper protection, e.g. wear a suitable glove or use a container with a long filling nose.

► Filling the evaporator

1. When you are filling the evaporator by hand, always remove the dish (A) first.
2. When you are using the sauna, the evaporator dish can get extremely hot. We advise using something to lift it up.

► Emptying the evaporator

3. The water outlet (B) is under the drain cock.
4. Put a suitable container (C) under the stove before turning on the drain cock.



NOTICE**Temperature in the cabin**

Please note that the relative humidity values vary greatly due to the different temperature distribution in the cabin. The display on the hygrometer and the display on the control unit may therefore be different.

NOTICE**Damage to the vaporiser from additives**

The water in the vaporiser can build foam and boil over if additives are added to it.

- Never add essences, essential oils or herbs to the water in the vaporiser; add them to the holder only.
 - If infusions accidentally get into the tank, the vaporiser must be emptied and cleaned. See Cleaning the Vaporiser.
 - Clean the sieve insert regularly to prevent corrosion!
-

7.5 Finnish sauna

In this operating mode, the vaporiser is not in operation. It is essential to ensure that there are no herbs or essences on the vaporiser attachment, as these could ignite due to overheating. Only add essences or infusions to the infusion water according to the manufacturer's instructions.

When adding an infusion at the end of the sauna session, you should not pour the water from the ladle over the stones too quickly so that the water evaporates completely and the full infusion effect is achieved.

CAUTION

Risk of burns!

The vaporiser attachment heats up during sauna operation. Therefore, never touch these parts during or shortly after sauna operation, or use a suitable aid if necessary.

WARNING

Risk of fire!

- Never place dry herbs or tea bags on the vaporiser attachment.
 - Always keep items placed on the sieve (e.g. lemon slices) moist, so top up with water regularly..
-

NOTICE

Appliance damage

- Only ever pour the infusion water over the area of the stones.
-

CAUTION

Risk of burns and scalding from hot steam

- Do not place your hand or arm in the vapour coming out of the spout
-

8. Maintenance

This sauna heater is made of corrosion resistant materials. To ensure a long service life, take care of and perform regular maintenance on your sauna heater.

Ensure that openings in the intake area and heat reflectors are never blocked. These can easily become blocked with lint and dust as fresh air is drawn in. This limits the air convection ability of the sauna heater and could lead to impermissible temperatures. Clean and/or descale the units as needed.

If you do not use your sauna for a longer period of time, ensure that at the time of recommissioning no towels or other objects are lying on the sauna heater or vaporiser.

Contact your sauna retailer or the manufacturer directly if you notice malfunctions or signs of wear and tear.

8.1 Cleaning

The heater must be cleaned regularly. The cleaning frequency depends on how often it is used. Clean the heater only with household cleaners.

CAUTION

Risk of injury from sharp edges

- Use suitable personal protective equipment, e.g. gloves, when cleaning parts with sharp edges.

► **Cleaning the heater**

1. Switch off the heater through the control unit. Allow the heater to cool down completely.
2. Clean the outer surfaces of the heater as necessary. Use only household cleaning agents.
3. Remove lint and dust from openings and heat reflectors. Openings can easily become blocked with lint and dust as fresh air is drawn in. This limits the air convection ability of the heater and could lead to excessive temperatures.

8.2 Sauna stones

Sauna stones are a product of nature. Sauna stones must be replenished or reshuffled regularly depending on the intensity of use.

The process of heating and cooling can make the stones brittle. Particular damage to the sauna stones can be caused by aggressive sauna essences, causing them to disintegrate over time. Small particles can break off from the stones. The gaps between the stones also become smaller which means that hot air can no longer rise between the stones. Check the sauna stones regularly and reshuffle them. Replace damaged stones. Please observe the following intervals.

Commercial use	Private use
Every 2-3 months	Once per year

Use only natural sauna stones when you replace the old stones with new ones. Due to their roughness, they produce a better water splash effect than ceramic sauna stones.

► Reshuffling the sauna stones

1. Switch off the heater through the control unit.
2. **CAUTION!** Stones may be hot. Allow the heater to cool sufficiently before you start to replace the stones. Remove each stone individually.
3. Check each stone for damage. Sort out any stones with notable damages.
4. Rinse all stones with cold water.
5. Place the stones loosely so that there is enough space between them for air to circulate sufficiently.

9. Service

9.1 Replacing the tubular heating element

Es können einzelne Rohrheizkörper oder das ganze Heizregister ausgetauscht werden.

Wenn der Ofen zu nah an einer Wand steht, muss er ggf. bewegt werden, damit alle Seiten erreichbar sind. Um den Ofen leichter bewegen zu können, müssen die Steine entnommen werden

Necessary steps:


- Removing the heating coil
- Replacing the tubular heating elements
- Inserting the heating coil

Hardware and tools:


- Tubular heating element or heating coil
- Screwdriver
- Allen key
- Ring or socket spannerl

► Removing the heating coil

1. **WARNING!** Ensure that the heater has been disconnected from all power supply lines.
 - a) Switch off the heater.
 - b) Switch off the fuses to disconnect the heater from the mains supply.
2. **CAUTION!** Allow the heater to cool down sufficiently before starting work, remove the stones.
3. Loosen the side panels (A) on the oven and slide them upwards to remove them.
4. Set the oven on its side.
5. Loosen the two fixing screws on the cover (B) of the connection box. Open the terminal box.
6. Loosen the four mounting screws on the collecting pan (C).
7. Disconnect the connection cables from the connection terminals.
8. Unscrew the four screws on the heating register.
9. Pull out the junction box with the heating register (D).




- A. side panel
- B. cover of junction box
- C. collecting pan
- D. heating register



► Replacing a tubular heating element

1. Identify the defective tubular heating element by taking measurements
2. Remove both flat plugs from the defective heating element.
3. Loosen the 2 fixing nuts and serrated washers on the defective heating element.
4. Remove the heating element.
5. Insert the new heating element.
6. Fix the heating element with the serrated washers and the fixing nuts
7. Plug in the flat plug.
8. Press check the wiring on all heating elements before reclosing the terminal box and setting up the heater.



- A. Tubular heating element
- B. Flat pin
- C. Fixing nut with toothed washers

► Inserting the heating coil

1. Insert the heating coil into the heater.
2. Screw in the 4 screws in the heating coil and tighten.
3. Connect the connecting cables.
4. Insert the lid of the junction box, the upper removable lid and the rear panel of the heater.
5. Screw in and tighten four fastening screws on the collecting pan.
6. Move the heater back into its original position.
7. Place the stones in the rock store.
8. Reconnect the heater and the control unit to the mains (restore the power supply).

9.2 Troubleshooting

Error	Reason	Solution
It takes the heater a long time to heat up the cabin.	One or more than one heating element is defective.	Have a technician replace the tubular heating element.
	There is not enough space between the stones.	Reshuffle the stones.
	There is insufficient ventilation.	Install the air inlets. If these are insufficient, add a fan to the openings.
	The electrical connection is defective	Check the installation fuses.
		Have the control unit's outputs checked by a technician.
The position of the temperature sensor is not optimal.	Check the position of the temperature sensor and adjust as needed.	
The heater is very hot but cannot distribute the heat throughout the cabin.	There is not enough space between the stones.	Reshuffle the stones.
The safety temperature limiter was triggered and the heater no longer heats.	The STL was triggered by heat accumulation.	Check the inlets, outlets, and the fan and ensure that the heater has access to a sufficient amount of air. Replace the safety temperature limiter.
	The position of the temperature sensor in the cabin is not optimal.	Check the position of the temperature sensor and adjust as needed.

Recycling



Devices or lighting elements that will not be used any longer have to be handed in at a recycling station according to regulation 2012/19/EU.



Do not dispose it with the normal household waste.

Packaging

The packaging of the unit can be completely separated for disposal and recycled. The following materials are used in the packaging:

- Paper/cardboard
- Plastic foil / plastic

Electronic waste

Electronic waste must be disposed of at the designated local collection point for electronic waste.

Additional disposal note for commercial users:

Further disposal instructions can be found under the link www.eos.sauna.de/recycling

Service Address

EOS Saunatechnik GmbH
Schneiderstriesch 1
35759 Driedorf
Germany

Tel: +49 (0)2775 82-514
Fax: +49 (0)2775 82-431
service@eos-sauna.de
www.eos-sauna.com

Please retain this address together with the installation guide for further references.

To help us answer your questions quickly and competently please provide the information printed on the type shield including the model, item no. and serial no., in all inquiries.

Date of sale:

Stamp and signature of the authorized dealer:

General Terms and Conditions of Service

I. Scope

Unless otherwise agreed in writing in a specific case, these terms and conditions of service shall apply to service operations, including examining and repairing complaints. All our existing or future legal relationships shall be governed solely by the following terms and conditions of service. Our recognition of any conflicting terms and conditions of the Ordering Party shall be conditional upon our having given our express written consent to their applicability. We hereby expressly object to any terms and conditions of the Ordering Party contained in its General Terms and Conditions of Business or order confirmation. If order confirmations or deliveries are accepted without reservation, this shall not be deemed to constitute recognition of such terms and conditions. Any ancillary agreements or amendments must be confirmed in writing.

II. Costs

The Ordering Party shall bear the following costs in connection with the service operation:

- De-installation/installation and electrical works (connection / disconnection).
- Transportation, postage and packaging.
- Function testing and troubleshooting including inspection and repair costs.

There shall be no third-party billing.

III. Obligations / Ordering Party's cooperation

The Ordering Party shall provide free-of-charge assistance to the manufacturer in carrying out the service operation.

By an accepted warranty claim the manufacturer shall provide the required replacement parts to the Ordering Party free of charge.

IV. Service visit by the manufacturer

In the event that it is essential that a manufacturer employee carry out the service operation on site, this must be agreed in advance. Where the main reason for the service call is not the fault of the manufacturer, any costs incurred shall be recharged to the Ordering Party after the service visit and shall be paid as per agreed payment terms.

V. Liability

The manufacturer shall assume liability in accordance with the currently applicable statutory regulations. The packaging for all of our products is designed for the shipping of individually packed

goods (pallet). We expressly point out that our packaging is not suitable for individual shipments via parcel post. The manufacturer shall accept no liability for damage incurred as a result of improper packaging in an individual shipment.

VI. Manufacturer's Guarantee

The manufacturer's guarantee shall apply only in the event that installation, operation and maintenance have been carried out in accordance with the manufacturer's specifications contained in the installation instructions and instructions for use.

- The guarantee period shall commence from the date on which proof of purchase is provided and shall be limited, in principle, to 24 months.
- Guarantee services shall be performed only if the original proof of purchase relating to the equipment can be presented.
- Any and all guarantee claims shall become void if modifications are made to the equipment without the manufacturer's express consent.
- Any guarantee claim shall likewise become void in the case of defects that arise due to repairs or interventions made by unauthorized persons or due to improper use.
- In the case of guarantee claims, the serial and article numbers must be indicated together with the product name and a meaningful description of the fault.
- This guarantee shall cover defective equipment parts, with the exception of usual wear parts. Wear parts are, among others, lamps, glass parts, heating elements and sauna stones.
- Only original replacement parts may be used within the warranty.
- Service visits by outside companies shall require a written order to be issued by our service department.
- The equipment in question shall be sent to our service department by the Ordering Party and at its expense.
- Electrical installation and connection works in the event of service or replacement shall be carried out at the Customer's expense and shall not be borne by the manufacturer.

Complaints in respect of our products shall be reported to the responsible authorized dealer and shall be exclusively handled via the latter.

The manufacturers General Terms and Conditions of Business, which can be found at www.eos-sauna.com/agb, shall apply in addition to the foregoing terms and conditions of service.

As of 08/2018