


SBM-LSG-IR

Relay Box for Infrared Cabins



Installation Instructions for Retailers

Made in Germany



Druck-Nr.: 2902 4982
Stand: 01/2019

Documentation

Manufacturer

EOS Saunatechnik GmbH	
Schneiderstriesch 1	
35759 Driedorf, Germany	
Tel.	+49 2775 82-0
Fax	+49 2775 82-431
Web	www.eos-sauna.com

Original installation instructions EN

Copyright for these installation instructions remains with EOS Saunatechnik GmbH.

Copyright as per DIN ISO 16016:

The copying and distribution of this document, as well as the use and communication of its contents without express authorization, are not permitted. Compensation will be claimed in the event of infringements.

All rights reserved with regard to patent claims or submission of design or utility patent.

Characters, symbols and illustrations

-  Additional information about an operating step
-  Cross-reference to a page
-  Read instructions
-  Result of a step
-  Table title
-  Title of figure

Revision history

Date	Version	Description
1 Feb. 2019	01.00	First version

Contents

Documentation	2
1 General safety instructions	5
1.1 Safety levels.....	5
1.2 Assembly and installation.....	6
1.3 Operator instructions	7
1.4 Standards and regulations	8
2 Identification	9
2.1 Unit specifications	9
2.1.1 Control unit.....	10
2.2 Intended use.....	10
3 Description of the unit	11
3.1 Scope of delivery.....	11
3.2 Overview of relay box.....	13
3.3 Internal view of relay box.....	14
3.4 Technical data	15
4 Installation	16
4.1 Power supply and data lines	16
4.2 Installation work inside the cabin	17
4.2.1 Installing an infrared emitter.....	18
4.2.2 Installing the temperature sensor	19
4.2.3 Installing cabin lighting.....	20
4.3 Relay box.....	21
4.3.1 Guidelines.....	21
4.3.2 Installing the relay box	24
5 Installation	28
5.1 Sample installation.....	29
5.2 Circuit board assignment.....	31
5.2.1 Terminals	32
5.2.2 Emitter type – jumper JP1 and JP2.....	32
5.2.3 Cabin address – programming button	33
5.2.4 Unit address – ADR DIP switch	33
5.2.5 Channels – DIP switches IR1 to IR3.....	34
5.3 Connection diagram	35
5.4 Connecting data lines	36
5.5 Connecting and configuring consumers	38
5.6 Setting the switches.....	40
5.7 Closing the relay box housing.....	42

6	Installing multiple cabins	43
6.1	Configuring 1-8 cabins.....	44
6.2	Control lines and cabin addresses	45
6.3	Programming the cabin address	46
7	Commissioning	49
7.1	Configuring the IR control system	50
7.2	EmoTouch 3	52
7.2.1	Configuring during commissioning or after a reset.....	53
7.2.2	Configuring the channel groups	54
7.3	Adjusting the IR emitters.....	56
7.3.1	Setting the IR operating mode.....	57
7.3.2	Setting the IR temperature	58
7.3.3	Setting the IR intensity.....	59
7.3.4	Switching hysteresis for the IR temperature.....	61
7.4	Defining the light source manually	62
7.5	Setting the heating period limiter	65
7.6	Troubleshooting	66
8	General terms and conditions of service	67
9	Disposal	70

1

General safety instructions

1.1 Safety levels

Safety instructions and important operating instructions are classified according to ANSI Z535.6. Please familiarise yourself with the following terms and symbols:

⚠ DANGER

Danger

Indicates a hazardous situation which, if not avoided, will result in death.

⚠ WARNING

Warning

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

⚠ CAUTION

Caution

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

Notice

Indicates a hazardous situation which, if not avoided, will result in damage to the unit.

General safety instructions

1.2 Assembly and installation



These installation instructions are intended for qualified personnel familiar with the laws and regulations applicable to electrical installations at the installation site. Observe the following general safety instructions during assembly, setup and commissioning.

Risk to life and limb and risk of fire

Risk to life and limb from electric shock and fire in the event of improper or faulty electrical connection. This risk also applies following completion of the installation work.

- ▶ The electrical installation of the relay box and other electrical systems or equipment with a fixed mains connection must only be performed by a trained electrician from an authorised electrical company.
- ▶ Observe the stipulations in VDE 0100 part 701.
- ▶ The system must be disconnected and removed entirely from the mains supply before commencing installation and repair work.
- ▶ The housing cover must only be removed by a specialist.
- ▶ Do not install control units, relay boxes and modules in enclosed cabinets or wood panelling.

Fire hazard from overheating

Infrared emitters and heating foils without overheat protection can lead to overheating of the cabin and fire. Flammable parts must not exceed a temperature of 140°C when the unit is operated as intended or in the event of a malfunction.

- ▶ Install only infrared emitters or heating foils that are designed and installed in such a way that they do not pose a fire hazard when the unit is operated as intended. Alternately, infrared emitters or heating foils with overheat protection as per EN 60335-2-53 may be used.
- ▶ Install a safety temperature limiter if needed.
- ▶ Observe the manufacturer's safety and installation instructions for infrared emitters and heating foils.
- ▶ Observe the cabin manufacturer's safety and installation instructions.

1.3 Operator instructions

The operator of the infrared or sauna cabin must be instructed in the general safety instructions during commissioning. The operator must be given a copy of the instructions for use.

- Risk of electric shock** A risk to life and limb from electric shock and fire arises in the event of improper repair work. This risk also applies after work is completed.
- ▶ The housing cover must only be removed by a specialist.
 - ▶ Repairs and installations must only be performed by a trained specialist.
 - ▶ The system must be disconnected and removed entirely from the mains supply before commencing repair work.
 - ▶ Use only original spare parts from the manufacturer.
- Risk of burns and chemical burns** Touching hot parts may lead to skin burns and chemical burns of the skin.
- ▶ The operator must be familiar with the unit's hot parts and be able to identify them.
 - ▶ The operator must be familiar with the settings for the heating period and understand how it is controlled.
- Health risks** Spending time in an infrared or sauna cabin can lead to serious health risks or even death for persons with health impairments.
- ▶ Persons with health impairments who spend time in a sauna must consult a doctor before entering an infrared or sauna cabin.
- Equipment damage due to overuse** Excessive humidity in commercial infrared or sauna cabins can lead to property damage.
- ▶ In a commercial infrared or sauna cabin, the heating period must be set so that it switches off automatically after a specific period of time.
 - ▶ If the heating period does not switch off automatically, cabin use must be supervised at all times.
 - ▶ Inspect the cabin before each use.

General safety instructions

Operation by children or persons with reduced mental capacity

- Children and persons with reduced mental capacity can be a risk.
- ▶ Children must be supervised to ensure they do not play with the unit.
 - ▶ Children under 8 should not operate the infrared cabin.
 - ▶ The settings for the heating period must only be used by children under 8 years of age if they are supervised by an adult.
 - ▶ The infrared cabin must only be used by persons with reduced mental capacity, or limited physical or sensory abilities under supervision or if they have already been instructed in its use and understand the risks.
 - ▶ Children and persons who have not received proper instruction must not clean or service the system.

1.4 Standards and regulations

The following standards, in their currently applicable versions, were observed during design and construction.

Local regulations also apply to the installation and operation of heating, sauna, and steam room systems.

Standard	Title
DIN EN 60335-1	Household and similar electrical appliances - Part 1: General requirements
DIN EN 60335-2-30	Household and similar electrical appliances – safety - Part 2-30: Particular requirements for room heaters
DIN EN 60335-2-53	Household and similar electrical appliances – safety – Part 2-53: Particular requirements for sauna heating appliances and infrared cabins
DIN EN 60335-2-96	Household and similar electrical appliances – safety - Part 2-96: Particular requirements for heating equipment
DIN EN 55014-1	Electromagnetic compatibility – Requirements for household appliances, electric tools and similar apparatus – Part 1: Emission
DIN EN 55014-2	Electromagnetic compatibility – Requirements for household appliances, electric tools and similar apparatus – Part 2: Immunity

2

Identification

The Relay Box for Infrared Cabins can be used for the following installations:

- in a multi-cabin installation with one infrared cabin and a compatible control unit as an add-on.
- in conjunction with a control unit to operate an infrared cabin.

2.1 Unit specifications

Nameplate

The nameplate is attached to the underside of the base of the housing.



- | | |
|---|-----------------------------|
| A Name | F Country of origin |
| B Model | G Manufacturer |
| C Item number | H Manufacturing date |
| D Operating voltage | I Serial number |
| E Switching output | |
|  Nameplate (example) | |

Requirements for operation and storage

The SBM-LSG-IR is only intended for installation outside the infrared cabin. The installation location must fulfil the following climate conditions:

- Ambient temperature during operation -10°C to 40°C
- Storage temperature -20°C to 60°C

Identification

2.1.1 Control unit

The Relay Box for Infrared Cabins can be operated with one of the following control units:

- EmoTec, EmoTec IR (software release R. 3.45 or higher)
- EmoStyle, InfraStyle (software release R. 3.45 or higher)
- EmoStyle i, InfraStyle i (software release R. 3.45 or higher)
- EmoTouch 3 (also SteamRock Premium) (software release R. 2.06 or higher)

Check your control unit's software version. Update your software if it does not match the specifications above.

Control units are not included in the Relay Box for Infrared Cabins's scope of delivery.

For more information about the control unit, see the relevant operating instructions and chapter Commissioning, [49](#).

2.2 Intended use

The Relay Box for Infrared Cabins is designed to operate infrared emitters and heating foils in infrared cabins. It must only be mounted on a wall. The IR module unit must be used in order to operate infrared heating foils and infrared emitters in a sauna cabin.

The Relay Box for Infrared Cabins is suitable for cabins used in private and commercial settings.

Foreseeable misuse

The following are considered instances of foreseeable misuse:

- The infrared heating foils do not have an integrated temperature sensor with overheat protection.
- The control and sensor cable plugs are plugged in incorrectly.
- The cabin addresses are programmed incorrectly.
- The unit is operated without knowledge of or compliance with the safety instructions.
- Operating, service and maintenance requirements are not observed.
- The unit is operated after technical or other modifications are made to the relay box.
- The unit is operated by children or persons with reduced mental capacity or by persons who have not been thoroughly instructed in its use.

 General safety instructions, [5](#)


3

Description of the unit

3.1 Scope of delivery

The relay box is enclosed in a plastic housing. The housing completely encloses the circuit board and the electronics.

The following components are included in the scope of delivery:



A Relay box with 2-piece front cover

B 5 bushings

C 3 wood screws 5 x 25 mm

D 10-m sauna bus connecting cable with RJ12/RJ12 modular plugs

E Installation and operating Instructions

F Temperature sensor including 5-m connecting cable with RJ10 plug, housing, circuit board, 2 screws 4x40 mm

G Power supply with connection cables

 Relay Box for Infrared Cabins scope of delivery

Check the scope of delivery for completeness prior to installation.


Description of the unit

Accessories (optional)

Accessories	Item no.
20-m connecting cable for temperature sensor	94.6281
50-m connecting cable for temperature sensor	94.6282
25-m connecting cable for control unit (RJ10/RJ14)	94.6285
10-m connecting cable for sauna bus (RJ12/RJ12)	94.5861
25-m connecting cable for sauna bus (RJ12/RJ12)	94.4647
50-m connecting cable for sauna bus (RJ12/RJ12)	94.4648
Power supply for extending the control unit's connecting cable to 50 m; only for EmoTouch 3 control unit	94.6671
IR module as installation add-on	94.6966
IR plug-in module with adapter cable	94.2046
IR plug-in module without adapter cable	94.4960
2.5-m connecting cable for IR plug-in module	94.4396

3.2 Overview of relay box

Housing




- A** Housing cover – top piece
- B** Housing
- C** Retaining screws for top piece
- D** Unit switch
- E** Retaining screws for bottom piece
- F** Housing cover – bottom piece


 Relay box

Unit switch


The relay box is equipped with an on/off switch on the left side.



Position I:
Relay box is switched on.
The relay box is ready for operation in standby mode.




Position 0:
Relay box is completely switched off.
Parts of the circuit board are still energized.



Position II:
Cabin light is switched on, relay box is switched off.
Position for maintenance and cleaning.

Description of the unit

3.3 Internal view of relay box



- | | |
|---|--|
| A Top mounting hole | E Housing cover fixtures – bottom piece |
| B Housing cover fixtures – top piece | F Lower mounting holes |
| C Unit switch | G Feed-throughs for cables with mains voltage |
| D Circuit board | H Feed-throughs for cables with low voltage |
|  Housing base | |

The cables for mains supply and low voltage can be routed through the existing holes on the back side or base of the housing.

For more information on the circuit board, see
5.2 Circuit board assignment,  31

3.4 Technical data

Ambient temperature	-10°C to +40°C
Storage temperature	-20°C to +60°C
Relay box housing	Plastic
Dimensions (H x W x D)	240 x 230 x 70 mm
Weight	Approx. 1.5 kg
Compatible control units (not included in scope of delivery)	EmoTec, EmoStyle, EmoStyle i, EmoTouch 3
Outputs/inputs	3 x RJ10 jack for sensor connection 2 x RJ12 jack for control unit and add-on modules Input for power supply plug
Power supply	230 V 1N AC 50 Hz
Switching output	Max. 3.5 kW
Circuits	3 separate circuits with total output of 3.5 kW, can be freely defined - 2 of which individually dimmable - 1 of which non-dimmable switching output
Temperature control	Based on ambient temperature: 30-70°C Based on personal preference using dimmable channels (zones)
Control characteristics	Digital output control on circuits 1 and 2
Connection for lighting	Min. 5 W (20 mA), resistive load, max. 100 W Dimmable energy-saving bulbs, max. 35 W Light source with conventional transformers, max. 60 VA Use only dimmable light sources.
Sensor system	Digital sensor for ambient temperature
Heating period limiter	Up to 6 hrs/12 hrs/infinite

4

Installation

This chapter describes how to install the relay box.

In a multi-cabin installation, all data lines and power supply cables must be routed and plugged in before installing the relay boxes and control units.

NOTICE

Equipment damage

Corrosive environments or environments with high levels of saline in the air could damage lines and circuit boards.

- ▶ Use the power unit only in non-corrosive environments.
- ▶ Salt aerosols should only be used inside the cabin.

4.1 Power supply and data lines

All electrical installations and all connecting lines routed inside the cabin must be suitable for an ambient temperature of at least 70°C in infrared-only cabins.

All lines must be routed in such a way that they are well-protected, e.g. in a cable conduit.

NOTICE

Electronics malfunctions

Routing data and power supply lines together can lead to electronics malfunctions because, e.g. because the sensor will not be detected.

- ▶ Do not route sensor and sauna bus lines together with power supply lines.
- ▶ Route separate cable conduits.

Line routing

The lines from the individual components to the power unit may not exceed 5.5 m in length.

If you connect more than one emitter per heating circuit, you must terminate the corresponding lines in the on-site plug-in modules outside the relay box. See  Example – plug-in modules (optional),  39


The control line must only be routed between the insulation and the outer wall of the cabin. Cabin insulation must be installed in such a way that the temperature in the area in which cables are routed cannot exceed 75°C.

Extending the control unit's control line

The control line may be extended to approx. 100 m, if necessary. The maximum line length for the EmoTouch 3 control unit is 25 m. For extra long connections, special RJ10/RJ14 connecting lines with a length of 10 m, 25 m, 50 m and 100 m are available as an option. Alternately, the 5-m line can also be extended with an RJ12/RJ12 coupling and an RJ12/RJ12 extension cord (optional accessory). If the line length is greater than 25 m, a special bus amplifier (accessory) with power supply must also be installed near the control unit and connected to it. The bus amplifier requires a 230-V mains connection.

4.2 Installation work inside the cabin

At minimum, the cabin lighting and a temperature sensor must be installed inside the cabin. Additional connections are possible, depending on the amenities, e.g. coloured lights and audio systems as optional add-on modules.



A Temperature sensor

B IR foil (installed inside the wall)

C IR emitter

 Example – cabin

The position and number of IR emitters and foils (IR emitters) can vary depending on the design of the cabin.

The temperature sensor must be installed where expected temperatures are the highest. In an infrared cabin, this is typically at the centre of the cabin ceiling.

NOTICE**Equipment damage due to improper installation**

Additional modules with a safety temperature limiter can be mounted in a cabin.

- ▶ Connect the safety temperature limiter only to the relevant module.
- ▶ Never connect more than one safety temperature limiter to a module.
- ▶ Always connect the safety temperature limiter as an isolated contact.

4.2.1 Installing an infrared emitter**⚠ WARNING****Fire hazard from overheating**

Infrared emitters and heating foils without overheat protection can lead to overheating of the cabin and fire. Flammable parts must not exceed a temperature of 140°C when the unit is operated as intended or in the event of a malfunction.

- ▶ Install only infrared emitters or heating foils that are designed and installed in such a way that they do not pose a fire hazard when the unit is operated as intended. Alternately, infrared emitters or heating foils with overheat protection as per EN 60335-2-53 may be used.
- ▶ Install a safety temperature limiter if needed.
- ▶ Observe the manufacturer's safety and installation instructions for infrared emitters and heating foils.
- ▶ Observe the cabin manufacturer's safety and installation instructions.

You can connect multiple IR emitters to terminals IR-1, IR-2 and IR-3. Ensure that the cross-section of the lines is sufficient.

The total output may not exceed 3.5 kW.

Connection	Control	Max. load	Total output
IR-1	Dimmable	1.5 kW	Max. 3.5 kW
IR-2	Dimmable	1.5 kW	
IR-3	Switchable	0.5 kW	

If terminals IR-1 and IR-2 together have a load of less than 2.3 kW, IR-3 can accept a maximum switching load of up to 1.2 kW. In this case, the fuse at

F2 (T4A H 250V) must be replaced by a T6.3 A H 250 V fuse. See 5.2 Circuit board assignment, 31.

Use a plug-in module if you want to connect multiple IR emitters to one connection.

See Example – plug-in modules (optional), 39.

4.2.2 Installing the temperature sensor


The temperature sensor must be installed where expected temperatures are the highest.

The IR control system prevents ambient temperatures from exceeding 70°C. Therefore, a safety temperature limiter is not needed in IR-only installations. The safety temperature limiter on the relay box's circuit board is therefore jumpered by default.

See IR relay box circuit board, 31.

Hardware + tools:

- Temperature sensor and connecting cables
- Drill to drill a hole in the cabin ceiling
- Screwdriver
- Taught wire, as needed



A Cabin ceiling

B Temperature sensor on housing

C RJ10 plug for relay box

Installation diagram


► Installing the temperature sensor in the cabin

1 Identify the installation site.

- ① The temperature sensor should be installed in the middle of the cabin ceiling. This is where the highest temperature in the infrared cabin is expected.

Installation

- 2 Drill a hole in the cabin ceiling for the cable.
- 3 **NOTICE** Do not pull at the plug when routing the control line(s). Doing so could damage the line. Attach the taught wire only to the cable. Route the sensor cable through the hole.
- 4 Open the temperature sensor's housing and connect the cable.



- A** White (sensor bus)
- B** Green (sensor bus)
- C** Brown (sensor bus)

 Connector pins for sensor bus

- 5 Screw the sensor to the cabin ceiling and close the housing.

 Connecting the sensor line:

 IR relay box circuit board,  31

4.2.3 Installing cabin lighting

Lighting can be installed anywhere, however not near rising hot air. The light output is set to inductive load by default, but light bulbs, halogen HV bulbs and other resistive loads may also be connected to it. If required, the light output can also be manually set to capacitive loads.

Setting the light output, see 7.4 Defining the light source manually,  62. Cabin lighting is not included in the scope of delivery. Observe the separate installation instructions for lighting.

Light source requirements:

- Minimal output 5 W
- Resistive loads max. 100 W
- Dimmable energy-saving bulbs max. 35 W
- Light sources with conventional transformers max. 60 VA
- Dimmable LED bulbs max. 60 W

NOTICE

Material damage

Lighting and the control panel could become damaged if non-dimmable light sources are installed. In this case, the warranty becomes void.

- ▶ Do not install lighting in the emitting range of an IR emitter.
- ▶ The lighting must conform to protection class IPX4 (splash-proof) and be resistant to ambient temperatures.
- ▶ Connect only dimmable light sources.

 Control line connection: Installation,  28

4.3 Relay box

The relay box must only be mounted outside of the cabin. Observe the following guidelines.


4.3.1 Guidelines

DANGER

Risk to life and limb and risk of fire

Risk to life and limb from electric shock and fire in the event of improper or faulty electrical connection. This risk also applies following completion of the installation work.

- ▶ Do not install relay boxes in enclosed cabinets or wood paneling.



 Proper and improper relay box installation

Installation

Recommended installation sites are:

- Outer wall of the cabin
- Utility room

If empty conduits for electrical installations are already present, this dictates the position of the relay box.

All lines should be routed before installing the relay box. Connections can be established later. Data lines must be routed and connected in such a way that they are not openly accessible.


NOTICE

Electronics malfunctions


Routing data and power supply lines together can lead to electronics malfunctions because, e.g. because the sensor will not be detected.

- ▶ Do not route sensor and sauna bus lines together with power supply lines.
- ▶ Route cable conduits separately.

Measurements for installation




☒ Back of relay box



☒ Installation diagram

Line routing



A Insulation

B Inner wall of the cabin

C Outer wall of the cabin

D Connecting lines

☒ Diagram – routing of data and control line(s)

The power supply, S bus and sensor lines can be routed to the relay box as follows:

- The lines can be routed along the outer wall of the cabin. They are then passed into the housing from below. If they are not routed through a

Installation

cable conduit or a duct, they must be secured so they cannot be pulled out.

- The lines can be routed between the insulation and the outer wall of the cabin. They are then passed into the housing from the rear.

In both cases, the cabin insulation must be installed in such a way that the temperature in the area in which cables are routed cannot exceed 75°C.

4.3.2 Installing the relay box

Necessary steps:

- ▶ Preparing for installation, [24](#)
- ▶ Removing the housing cover, [24](#)
- ▶ Installing the relay box, [25](#)

Tools + hardware


- Drill
- Wood screws 4 x 25 mm
- Mounting on a fixed wall: Screws 4 x 25 mm and corresponding anchors

▶ Preparing for installation


- 1 Identify the installation site.
- 2 Route the lines.

▶ Removing the housing cover

- 1 Unscrew the 6 screws for both parts of the housing.



- 2 Remove both halves of the cover.
 - ① If you have already routed all data lines, you can set the DIP switches on the circuit board after you install the relay box.
- 3 Open the relay box conduits for the lines.



- A** Lines with mains voltage, e.g. mains supply line, heat **B** Lines with low voltage, e.g. sensor line, S bus (sauna bus)

① Either from below or from the rear.

- 4 Insert supplied rubber grommets into the openings of the lower part of the housing.

► Installing the relay box


- 1 Drill one (1) hole above and two (2) holes below.

Horizontal distance between drill holes: 210 mm

Vertical distance between drill holes: 180 mm


Installation

- 2 Insert the anchors as needed and screw in the top screw.



- ⓘ Allow the screw to protrude approx. 3 mm so you can hook in the relay box.


- 3 Route the connection cables through the openings.



- A** Lines with mains voltage, e.g. mains supply line, heat
B Lines with low voltage, e.g. sensor line, S bus (sauna bus)

- ⓘ Either from below or from the rear.


- 4 Hook the relay box into the upper screw using the upper mounting hole.



- A** Top mounting hole

- B** Lower mounting holes

- 5 Securely tighten the relay box using the two lower mounting holes.



- ① Once you have completed all installation work you can connect the consumers and plug in the lines.
- ① 5.4 Connecting data lines, [p 36](#)
- 5.5 Connecting and configuring consumers, [p 38](#)
- 5.6 Setting the switches, [p 40](#)

5

Installation

This chapter describes how to connect the relay box's circuit board lines. For information on configuration of the control unit's panel, see chapter Commissioning, [p 49](#).

You can connect both infrared radiators and infrared foils. Both versions are referred to as IR emitters in the following section. However, in instances where different settings must be made, they will be referred to specifically by name.

Recommended installation sequence

Before commencing installation, ensure that the relay box and the control unit are mounted. Furthermore, all cabin work must be complete: IR emitter, temperature sensor, lighting, etc.

Complete installation in the following sequence:


- Plug the S bus and sensor lines into the relay box.
- Connect the consumer lines to the relay box.
- Set the DIP switch for the unit address.
- Set the jumper for the IR emitter to IR-1 and IR-2.
- Set the DIP switch for the channels.
- Establish connection to the power supply.
- Switch on the relay box and control unit.
- Configure the control unit's channels.
- Configure additional settings at the control unit, e.g. target temperature for emitters.

5.1 Sample installation

An installation can have and control one or more than one IR cabins with IR emitters. The following examples assume only one cabin is installed. A multi-cabin installation is described separately. See [Installing multiple cabins](#), 43

Standard installation

A standard installation has one single installed infrared relay box. The IR emitters, lights, temperature sensors and control unit are connected to this relay box.



- | | |
|------------------------------------|-----------------------------|
| A Cabin lighting | E Temperature sensor |
| B SBM-LSG-IR | F IR emitter |
| C Control unit | G Power supply |
| D Add-on modules (optional) | H Power supply |

 Standard installation for one cabin


Multiple infrared emitters or IR foils (IR emitters) and other modules can be connected via the relay box. All connected modules are controlled by the control unit.

You must integrate a plug-in module if you connect multiple IR emitters to a terminal.

Installation

Advanced installation

A maximum of 2 infrared modules may be connected to the SBM-LSG-IR in an advanced installation.



A Relay box (unit 1)

B IR module (unit 2)

C IR module (unit 3)


 IR relay box with connected IR modules

For control purposes, the relay box and module are identified by unit addresses.

Bus communication can be adversely affected if the cabin is equipped with an extremely high number of add-on modules. To rectify the problem, ensure the modules have their own single power supply.

5.2 Circuit board assignment

The S bus and sensor bus plugs are connected to the relay box circuit board. The IR emitters and the cabin lighting must be connected to the terminals.



- | | |
|--|---|
| <p>A Fuse for light output</p> <p>B Cabin lighting connection (L+N for lighting only)</p> <p>C Main power supply connection</p> <p>D Connection for switched IR emitters</p> <p>E Fuse F2 (T4A H 250 V)</p> <p>F Connections for dimmable IR emitters</p> <p>G Power supply connection</p> <p> IR relay box circuit board</p> | <p>H Safety temperature limiter/jumper</p> <p>I Sensor bus</p> <p>J DIP switch – unit address, channels</p> <p>K S bus (sauna bus)</p> <p>L Programming button for cabin address</p> <p>M Status LED, green and red</p> <p>N Jumper – setting for foil/emitter</p> |
|--|---|

If terminals IR-1 and IR-2 together have a load of less than 2.3 kW, IR-3 can accept a maximum switching load of up to 1.2 kW. In this case, the fuse at F2 (T4A H 250V) must be replaced by a T6.3 A H 250 V fuse.

5.2.1 Terminals

Multiple IR emitters can be connected to terminals IR-1, IR-2 and IR-3. The IR emitter lines must all have the same cross-section.

The terminal for lighting may be assigned only one line. It must only be used for cabin lighting.


Use a plug-in module if you connect multiple emitters to one terminal.

See 5.5 Connecting and configuring consumers, [□ 38](#)

5.2.2 Emitter type – jumper JP1 and JP2

JP1 and JP2 are used to configure the emitter type for connections IR-1 and IR-2.


- R: IR emitter (R).
- F: IR foil (F).




Emitters (R) are connected to IR-1 and IR-2.



Foils (F) are connected to IR-1 and IR-2.



Emitters (R) are connected to IR-1; foils (F) are connected to IR-2.




Emitters (R) are connected to IR-1.
IR-2 is switched off.

Connection IR-3 is configured for emitters at the factory.

Connections IR-1 and IR-2 are switched off if no jumper is set. IR-3 remains switched on.

5.2.3 Cabin address – programming button

The Relay Box for Infrared Cabins is programmed with cabin address 1 as delivered. If multiple cabins are installed, the cabin address must be programmed accordingly in the respective relay boxes.



A LED

B Programming button

Programming button – IR relay box

For more information about installing multiple cabins, see chapter Installing multiple cabins, 43.

5.2.4 Unit address – ADR DIP switch

Each connected IR module is assigned a unique unit address. Each unit address must only be assigned once so that the unit can be uniquely identified.

One IR relay box and 2 IR modules per cabin are supported. Control loops for the three units are controlled simultaneously.

Typically, the relay box is assigned unit address 1. Additional modules are assigned addresses 2 and 3 respectively in the IR modules.

Address 1 (unit 1)	Address 2 (unit 2)	Address 3 (unit 3)
<p>ADR</p>	<p>ADR</p>	<p>ADR</p>
DIP switch 2-3 = ON	DIP switch 1-4 = ON	DIP switch 5 = ON

5.2.5 Channels – DIP switches IR1 to IR3


IR emitters can be grouped into channel groups and controlled simultaneously. A group can comprise various IR emitters. Channels A-E are available for these groups.

The assignment of the IR connections to a channel can be set globally, e.g.:

Unit/module	Channel IR1	Channel IR2	Channel IR3
Module 1	A	A	C
Module 2	B	A	C
Module 3	D	D	E

Standard channel group configuration


If emitters are connected to output IR-3 and emitters or foils are connected to outputs IR-1 and IR-2, the DIP switches for the channel groups are set as follows.

Example	Channel IR1 to IR3	1	2	3	4	5	
 <p>Example – channel A</p>	A	ON					
	B		ON				
	C				ON		
	D					ON	
	E						ON

Do NOT combine dimmable and switchable IR emitters in one channel group.


Foils at IR-3

If foils are connected to output IR-3, the channels at IR3 must be set as follows:

Foils at IR-3	Channel	1	2	3	4	5
 <p>IR3</p> <p>Example – channel A</p>	A		ON	ON	ON	ON
	B	ON		ON	ON	ON
	C	ON	ON		ON	ON
	D	ON	ON	ON		ON
	E	ON	ON	ON	ON	


IR emitter at IR-3 starts when cabin is switched on

If you would like the IR emitter assigned to the IR-3 output to switch on when the cabin is switched on, the DIP switches in IR3 must all be set to OFF.



5.3 Connection diagram

The relay box is connected with a mains lead to the 230-V supply and fused separately with 16 A. At minimum, a 16-A cut-out with c characteristic must be used for fuse protection.



☒ Connection example

To prevent overheating, install only infrared emitters or heating foils that are designed and installed in such a way that they do not pose a fire hazard

when the unit is operated as intended. Alternately, infrared emitters or heating foils with overheat protection as per EN 60335-2-53 may be used.

5.4 Connecting data lines

NOTICE

Equipment damage due to improper installation


Additional modules with a safety temperature limiter can be mounted in a cabin.

- ▶ Connect the safety temperature limiter only to the relevant module.
 - ▶ Never connect more than one safety temperature limiter to a module.
 - ▶ Always connect the safety temperature limiter as an isolated contact.
-

▶ Connecting data lines

- 1 DANGER! Ensure that the IR relay box is current-free.
Open the housing as needed.
 - ⓘ ▶ Removing the housing cover, [p. 24](#)

- 2 Route the line through the openings at the base or on the back of the housing.



- | | |
|--------------------------------------|--|
| A RJ14 plug from control unit | D Temperature sensor |
| B RJ10 plug for sensor line | E Safety temperature limiter |
| C Power supply connection | F Jumper at safety temperature limiter terminal |

- 3 Plug the S bus line RJ10/RJ14 from the control unit into the free jack RJ14 (S-BUS).
- 4 Plug the sensor line from the temperature sensor into the free jack RJ10 (SENSOR).
 - ① The connected sensor is automatically recognized and configured by the control unit.
 - ① Connect shielding of the line to ground if necessary.
- 5 Check if there is a jumper at the safety temperature limiter terminals.
 - ① By default, the safety temperature limiter terminal is jumpered at the relay box circuit board. A safety temperature limiter is not needed for an IR-only installation, since temperatures above 70°C cannot be reached by the IR emitters.

5.5 Connecting and configuring consumers



⚠ DANGER

Risk of electric shock

A faulty electrical connection poses the risk of an electric shock. This risk also applies following completion of the installation work.

- ▶ Disconnect the system entirely from the mains supply.
 - ▶ If retrofitting is required, the housing must only be opened by trained personnel.
 - ▶ Electrical installation must only be carried out by a qualified and licensed electrician.
 - ▶ The unit must be connected to the power supply according to the circuit diagram and the terminal scheme.
-

Recommended sequence:

- Connect IR emitter
- Set jumper
- Connect cabin lighting


The lines from the individual components to the relay box may not exceed 5.5 m in length. The lines must be connected as shown in the circuit diagram.

You can connect multiple IR emitters to each of the terminals IR-1, IR-2 and IR-3. The IR emitter lines must all have the same cross-section. The total output of IR-1, IR-2 and IR-3 together may not exceed 3.5 kW. Recommendation:


Connection	Control	Total output
IR-1	Dimmable	Max. 1.5 kW
IR-2	Dimmable	Max. 1.5 kW
IR-3	Relay output	Max. 0.5 kW

If terminals IR-1 and IR-2 together have a load of less than 2.3 kW, IR-3 can accept a maximum switching load of up to 1.2 kW. In this case, the fuse at F2 (T4A H 250V) must be replaced by a T6.3 A H 250 V fuse.

If you connect more than one emitter per heating circuit, you must connect all lines to a plug-in module outside the relay box.



Example – plug-in modules (optional)



- A Cabin lighting connection
- B Main power supply connection

- C IR emitter connection
- D Power supply connection

► Connecting consumers

- 1 DANGER! Ensure that the IR relay box is current-free. Open the housing as needed.
 - ① ► Removing the housing cover, 24
- 2 Route the lines through the openings at the base or on the back of the housing.

- 3 Connect IR emitters to IR-1, IR-2 and IR-3 (C).
Use a plug-in module if you connect multiple IR emitters to one terminal.
See  Example – plug-in modules (optional),  39
 - ⓘ The IR emitter lines must all have the same cross-section.
 - ⓘ Observe the total output:
IR-1 max. 1.5 kW, IR-2 max. 1.5 kW, IR-3 max. 0.5 kW.
- 4 Connect the cabin lighting to the light (A) terminal.
- 5 Connect the main power supply to the mains (B) terminal.
- 6 Connect the power supply to the 24-V DC jack (D).
 - ⓘ Do not establish a connection to the power supply until you have set all switches. See 5.6 Setting the switches,  40.

5.6 Setting the switches

Once the IR emitters are installed and connected, the jumpers for the type of emitters and channel groups must be set. As a rule, the unit address for the relay box must not be changed.


The cabin address must only be programmed if the installation is a multi-cabin installation.

See 6.3 Programming the cabin address,  46

- ▶ Setting the jumper for the type of IR emitters,  40
- ▶ Setting the unit address,  41
- ▶ Setting channel groups for IR emitters,  41

▶ Setting the jumper for the type of IR emitters


- 1 DANGER! Ensure that the IR relay box is current-free.
Open the housing as needed.
 - ⓘ ▶ Removing the housing cover,  24



- 2 Set jumpers JP1 and JP2 to foil (F) or emitter (R) depending on the connected emitters.
See 5.2.2 Emitter type – jumper JP1 and JP2, 32

► Setting the unit address


- 1 Set the unit address as needed.



- ① The relay box is set to address no. 1 by default. As a rule, this setting must not be changed.

► Setting channel groups for IR emitters

- 1 Assign the IR connection with DIP switch to a channel group.
① See Installation example, 51.



See 5.2.5 Channels – DIP switches IR1 to IR3, 34

- ① Only 1 DIP switch may be set to ON at one time.

Examples:

Switch 1 = ON: Channel group A

Switch 2 = ON: Channel group B

Switch 3 = ON: Channel group C

You can assign the IR outputs to the same channel group, e.g. IR-1 and IR-2 to channel group A, IR-3 to channel group B.


5.7 Closing the relay box housing

The following work must be completed before you close the housing:

- 5.4 Connecting data lines, [p 36](#)
- 5.5 Connecting and configuring consumers, [p 38](#)
- 5.6 Setting the switches, [p 40](#)

► Replacing the housing cover


- 1 Connect the power supply to the 24-V DC jack.
- 2 Put the upper and lower cover halves in place.
- 3 Screw in the 6 screws.



6


Installing multiple cabins

The EmoTouch 3 control unit can be used to set and control multiple cabins. Any combination of up to 8 sauna, infrared and/or steam cabins can be connected, e.g.:



Installing multiple cabins

6.1 Configuring 1-8 cabins



 Operating mode – standard

 In this operating mode, one steam generator or one sauna heater is operated per cabin.

The lines are connected as follows:


Cabin no.	Relay box connection – control unit	Cabin address
1	The relay box is connected to the jack #1 of the control panel using the sauna bus cable.	
2	The relay box is connected to a free sauna bus jack in the relay box of cabin #1.	Relay box is set to address 2.
3	The relay box is connected to jack #2 of the control panel using the sauna bus cable.	Relay box is set to address 3.
4	The relay box is connected to a free sauna bus jack in the relay box of cabin #3.	Relay box is set to address 4.
5	The relay box is connected to jack #3 of the control panel using the sauna bus cable.	Relay box is set to address 5.
6	The relay box is connected to a free sauna bus jack in the relay box of cabin #5.	Relay box is set to address 6.
7	The relay box is connected to jack #4 of the control panel using the sauna bus cable.	Relay box is set to address 7.
8	The relay box is connected to a free sauna bus jack in the relay box of cabin #7.	Relay box is set to address 8.

See also the following figures:

-  Jacks – SBM-LSG-IR, [45](#)
-  Jacks – EmoTouch 3 circuit board, [45](#)


6.2 Control lines and cabin addresses

Control lines must only be plugged into the corresponding jacks on the circuit boards of the control units and relay boxes.



A RJ14 plug from control unit **B** RJ10 plug for sensor line

☒ Jacks – SBM-LSG-IR




☒ Jacks – EmoTouch 3 circuit board

Installing multiple cabins

Ferrite ring per jack

One jack per connection must be fitted with 1 ferrite ring.



The ferrite ring for jack #1 is included in the scope of delivery for each control unit and add-on module.

Once the cabins with their custom cabin address (IDs) are connected, the icon of the connected cabin appears in the footer.



The number corresponds to the cabin currently selected (not the number of connected cabins).

6.3 Programming the cabin address

The relay box is programmed with cabin address 1 as delivered. To ensure that EmoTouch 3 detects multiple cabins, the cabin address must be changed to a different cabin address starting with cabin 2.

To program the cabin addresses, you must open the housings of the relay boxes and the EmoTouch 3 control unit housing and plug in the S bus lines. Ensure that you observe the connection sequence.

The connection sequence must start with jack #1 on the EmoTouch 3 circuit board. See [Jacks – EmoTouch 3 circuit board](#), 45


Cabins with incorrect connections will not be detected or displayed on the control panel.

In installations with EmoTec and EmoStyle control units, relay boxes are always assigned cabin address 1.

► Programming the address


- 1 Open the relay box's housing as needed.
 - ① ► Removing the housing cover, 24
- 2 Open the control unit.

3 Pull the S bus line from the relay box through the ferrite ring twice.



4 Slide the ferrite ring onto the bridge on the mounting plate.


5 Connect control lines to socket 1/2 using the RJ10 plugs.



EmoTouch 3 circuit board – jacks

① Plug for multi-cabin connection, see [Installing multiple cabins](#), 43

6 **NOTICE** You must follow the correct connection sequence. If the cabin address does not match the connection, the cabin is not detected. Press and hold the programming button on the circuit board of the relay box for approx. 4 seconds until the red LED starts flashing.



① Programming mode is active. The green LED light goes off.

Installing multiple cabins

- 7 Quickly press the programming button once for each new address. As delivered (address 1), this means:
 - a) Press once for cabin 2. The LED flashes twice.
 - b) Press twice for cabin 3. The LED flashes three times.
 - c) Press three times for cabin 4. The LED flashes four times.
 - d) Press four times for cabin 5. The LED flashes five times.
 - e) Press five times for cabin 6. The LED flashes six times.
 - f) Press six times for cabin 7. The LED flashes seven times.
 - g) Press seven times for cabin 8. The LED flashes eight times.
 - ⓘ Note that each time you press the programming button, the cabin address increases by one. Once address 8 is reached, the count start over with address 1.
 - ⓘ The green LED flashes 1 to 8 times, depending on the new cabin address.
 - ☑ If the button is not pressed for approx. 10 seconds, programming mode ends. The red LED goes off and the green LED starts flashing. The new address is saved.
 - ⓘ If power is lost, the most recent cabin address setting is automatically saved.

- 8 Check the control panel to verify if the cabin is displayed on the screen.



 - 🖨 Example – display for cabin 3

- 9 Repeat programming if the cabin is not displayed.
 - ⓘ Please note that the address increases by one each time you press the programming button, e.g. from 4 to 5.

- 10 Close the housing of the relay box and control unit.
 - ⓘ ► Replacing the housing cover, 📄 42

7

Commissioning

The term IR emitter refers to infrared emitters and heating foils in the following documentation.

In order to commission the cabin with the installed IR emitters, the cabin must be switched on at the control unit. If the display is blank, the relay box might be switched off.

An on/off switch is located on the left side of the relay box.



Position I:
Relay box is switched on.
The relay box is ready for operation in standby mode.



Position 0:
Relay box is completely switched off.
Parts of the circuit board are still energized.



Position II:
Cabin light is switched on, relay box is switched off.
Position for maintenance and cleaning.

7.1 Configuring the IR control system

The control system cannot be configured until the IR emitters are installed and connected. The following describes only how to configure the IR emitters. Complete configuration and operation are described in the operating instructions for EmoTouch 3.

You should be familiar with the basic operating steps, e.g. navigating the menus and sub-menus and entering and saving settings.

Icons


The following icons are used to assign the IR emitters.

	Front middle		Front right
	Front left		Back middle
	Back left		Back right
	Leg		Ceiling
	Floor		Side right
	Side left		IR group 1
	IR group 2		IR group 3
	IR group 4		IR group 5

Each icon may be assigned only once.

Installation example

To make configuration easy to understand, the following example shows which switches must be set.



☒ Example – cabin

The IR emitters in this example have different tasks and should be controlled together in so-called channel groups.

- IR emitters 1, 2 and 3 are emitters for the back. Together their output is 1.5 kW.
- IR emitters 4 and 5 are foils for the heating the back with an output of 0.3 kW each. They should heat to an intensity of 66%.
- IR emitters 6 and 7 are corner emitters. Together their output is 0.5 kW. They should switch off once the cabin temperature reaches 65°C.

Emitter	Connection	Jumper	Channel
1, 2, 3	IR-1	Emitter (R)	A
4, 5	IR-2	Foil (F)	B
6, 7	IR-3		C

7.2 EmoTouch 3

The graphic user interface displays icons depending on the selection. Their use is described below:



Tap briefly on the cabin image: The function is switched on or off.

Tap briefly on the sub-menu: The icon is selected.

Tap again: The selection is confirmed.

Press and hold: A sub-menu opens.

Tap anywhere on the cabin image: The sub-menu for settings closes.



Cabin on/off



Settings



Next



Back to previous selection or start



Confirm selection



Clear selection



Increase the value by 1



Decrease the value by 1

The home screen (standby) appears after the display has not been touched for 10 seconds.

- Settings that have not been saved are lost.
- Date and time are saved if the built-in battery is in working order. All other settings are saved permanently.

Add-on modules or accessories are detected once the unit is switched on again and their corresponding icons appear on the cabin image or in the sub-menus. Unit operation and unit settings are available on different levels:

Operation level	Private operation	
	Commercial operation	Basic settings
		Advanced settings (with PIN code)
Service level	Settings for service technician (with PIN code)	

7.2.1 Configuring during commissioning or after a reset

The basic settings must be defined to commission the unit. The program guides you through the required steps.

The home screen automatically appears after the control panel has not been touched for 10 seconds. Settings that have not been saved are lost.

► Defining the basic settings

- 1 Select a language and confirm.
- 2 Set the time and confirm.
- 3 Set the date and confirm.
- 4 Specify the type of use and confirm:

a)  Private use

b)  Commercial use

① Specific safety regulations apply to this setting. See 1.3 Operator instructions, [7](#)

If you use the EmoTouch 3 to operate sauna cabins and steam rooms in addition to the IR cabin, initial configuration involves additional steps, e.g. heater selection, cabin views, etc. These steps are described in the installation and operating instructions for the sauna and steam room relay boxes. You must select and configure the IR intensity and/or IR temperature operating modes once the channel groups are configured.

See 7.2.2 Configuring the channel groups, [54](#)

Commissioning

7.2.2 Configuring the channel groups


The settings are configured as shown in the example above. See Installation example, [p 51](#)

► Configuring the IR channel groups


- 1 Select the cabin.
- 2 Tap and hold  for 3 seconds.
- 3 Enter code **5349** and confirm.



- 4 Tap  and confirm the selection.




5 Select a channel and confirm the selection.



① Ensure that the selected channel is configured at the circuit board.

6 Select the IR emitter icon and confirm.



① You may assign each icon only once.

7 Follow the same steps to configure the next channel group.

7.3 Adjusting the IR emitters

The IR emitters have two operating modes.

These operating modes let you determine how the IR emitters can be used: via intensity and/or temperature.

Operating mode	Temperature	Intensity
	Ambient temperature can be set via temperature sensors Emitters heat until the temperature has been reached	All channel groups at 100%
	Ambient temperature increases slowly via channel group intensity	Can be set for each channel group

IR intensity operating mode

The following settings are available in IR intensity operating mode for outputs IR-1 to IR-3:

Foils at IR-3	Emitter at IR-3	Foil at IR-1, IR-2	Emitter at IR-1, IR-2	Intensity setting
x	x			0% or 100%
		x		20% to 100%, in increments of 2%
			x	15, 25, 33, 50, 66, 75, 100%

IR temperature operating mode

The following settings are available in IR temperature operating mode for outputs IR-1 to IR-3:

Foil at IR-1, IR-2, IR-3	Emitter at IR-1, IR-2, IR-3	Control mode for relay output
x	only IR-1 and IR-2	Control via T (target)
	x	Switch-off > 70°C

The connection for switching output IR-3 is not controlled via the temperature of the IR emitter, but rather switched off when the ambient temperature reaches 70°C. In Foil operating mode, it is controlled via the ambient temperature sensor.

Note that the intensity and temperature settings impact the duration of the heat-up phase.

7.3.1 Setting the IR operating mode

After installation, you can set the operating mode, temperature and/or intensity for each IR cabin. You can also define the switching hysteresis for the IR emitters.

The following icons are displayed for selection.



IR temperature operating mode:

You can set the temperature of the IR emitters and the intensity per channel.





IR intensity operating mode:

You can set the intensity of the IR emitters per channel.

► Setting the operating mode

- 1 Press and hold the emitter icon for 5 seconds.



Commissioning

2 Select the operating mode and confirm.

a)  IR intensity.

b)  IR temperature.

7.3.2 Setting the IR temperature

You can set the temperature only after you have selected the IR temperature operating mode. ► Setting the operating mode, [p 57](#)


You can also set the temperature while the system is in operation. The temperature applies to all IR emitters.

The ambient temperature in the IR-only cabin cannot exceed 70°C. This maximum temperature cannot be exceeded even if all IR emitters are operating at full intensity.


► Setting the IR temperature

1 Select the cabin.

2 Tap the IR emitter icon.



- 3 Move the slider to the desired temperature.




- The emitter is immediately set to the new temperature.

7.3.3 Setting the IR intensity

You can set the intensity once you have selected either the IR temperature or IR intensity operating mode. ► [Setting the operating mode](#), 57
 You can set the intensity of the IR emitters while the system is in operation. It generally applies to one channel group.

► Setting the IR emitter intensity


- 1 Select the cabin.
- 2 Tap the IR emitter icon.



- The menu with the current setting appears.


Commissioning

- 3 Tap  to switch to the intensity settings as needed.



ⓘ The first channel group is displayed first.

- 4 Move the slider to the desired intensity.




ⓘ The selected channel group's icon appears above the slider.

ⓘ Only 0% or 100% may be selected for emitters at the IR-3 connection; 20%-100% for foils.

☑ The channel group emitters are immediately set to the new intensity. This means they are not set to the target temperature.

- 5 Tap  to switch to the next channel group as needed.



7.3.4 Switching hysteresis for the IR temperature


In the service settings, you can also set a temperature range within which the IR emitters are switched on and off. It applies to all connected IR emitters.

Example — 46°C target temperature and hysteresis 4 K: The IR emitter is switched off at 48°C and switched on at 44°C.

► Adjusting the hysteresis

- 1 Tap and hold  for 3 seconds.
- 2 Enter code **5349** and confirm.
- 3 Tap  and confirm the selection.

- 4 Set the value with **+** and **-**, and then confirm.



ⓘ The value can be set to any number between 1 and 5.

7.4 Defining the light source manually

The control unit is set to inductive loads by the factory so that resistive loads can also be controlled by the control unit. If required, the light output can also be manually set to capacitive loads.

If light bulbs are used, the load for lighting must remain as an inductive load.

The current setting is shown on the display.

Display symbol	Setting	Code
	Inductive/resistive load, if light bulbs are used. Factory setting	8001
	Capacitive load Electrical ballasts for phase-cut dimmer	8002

NOTICE


Material damage

Improper setup can damage the unit. In this case, the warranty becomes void.

- ▶ Work must only be performed by a trained technician from an authorised company specialised in the trade.

► Setting the load for lighting to resistive load



- 1 Open the relay box's housing as needed.
 - ① ► Removing the housing cover, [p 24](#)
- 2 **DANGER!** Ensure that the relay box is disconnected from the power supply.
Disconnect the light source from the main circuit board.
- 3 Switch on the relay box and control unit.
- 4 Tap and hold  for 3 seconds.
- 5 Enter the code and confirm.



- ① Code **8001**: Inductive load/resistive load, e.g. if light bulbs are used.
 - ① Code **8002**: Capacitive load, electrical ballasts for phase-cut dimmer.
- 6 Disconnect the relay box from the mains supply and reconnect the light source.
 - 7 Close the housing again.
 - ① 5.7 Closing the relay box housing, [p 42](#)
 - 8 Reconnect the relay box to the power supply.

Commissioning

- 9 Press and hold the lights on the display for 3 seconds.



- ① The icon for the current lighting load setting is displayed.

- 10 Check the setting on the display.

7.5 Setting the heating period limiter

For private use, the heating period is limited to 6 h.

For commercial use, the heating period can be set to 6 h, 12 h or infinite.

Heating period	Code
6 hours	8206
12 hours	8212
Unlimited 24 hours/7 days a week	8224

The codes for the heating period limiter are exclusive to infrared-only installations.

In mixed operation, IR emitters are installed in a sauna cabin. For this installation, the heating period limiter is set with jumper 5 on the sauna relay box,. This overrides the codes listed above.

► Setting the heating period

- 1 Tap and hold  for 3 seconds.
- 2 Enter the code and confirm.



- ① Code **8206**: 6 hours.
- ① Code **8212**: 12 hours.
- ① Code **8224**: 24 hours/7 days a week.

Commissioning

7.6 Troubleshooting

Error message and icons on the control panel indicate SBM-LSG-IR operating statuses and fault conditions.

Fault	Reason	Solution
Control panel display is blank	No power supply.	Switch on the relay box.
		Check the relay box's mains connection.
		Check fuses.
		Check the power supply
IR temperature cannot be set	Channels are not set.	Define channel groups.
Communication error	Sauna bus not plugged in.	Check data line and connections.
	Jumpers not set.	Set JP1 and JP2 for connections IR-1 and IR-2.
	IR module is disconnected.	Set the heater operating mode.
	Channel groups not defined.	Define channel groups.
IR emitters do not heat.	Unit not detected.	Set unit address for the module.
Cabin is not displayed.	Cabin is not detected.	Check and set cabin address. Check the sequence of connections.
Thermo-fuse tripped.	Temperature too high.	Check cause of excess temperature. Replace fuse.
Unknown error.		Restart unit. Contact technical support.
No bus communication	Too many add-on modules connected.	Connect IR module with separate power supply.
	Bus connection plug not plugged in.	Plug in plug.
	Bus cable damaged.	Replace bus cable.

8

General terms and conditions of service

(T&C, Dated 08-2018)

I. Scope

Unless otherwise agreed in writing for specific instances, these terms and conditions of service shall apply to service operations, including reviewing and remedying complaints. All our existing or future legal relationships shall be governed solely by the following terms and conditions of service. We do not recognise any of the customer's conflicting terms and conditions unless we have given our express written consent to their applicability.

We hereby expressly object to any of the customer's terms and conditions included in the customer's General Terms and Conditions of Business or order confirmation. Unconditional acceptance of order acknowledgments or deliveries shall not be construed as any form of acknowledgment of such terms and conditions. Ancillary agreements or amendments must be confirmed in writing.

II. Costs

The customer shall bear the following costs in connection with services rendered:

- Disassembly/assembly and electrical (de-)installation
- Transportation, postage and packaging
- Function testing and troubleshooting, including inspection and repair costs

There shall be no third-party billing.

III. Performance and cooperation obligations

The customer shall provide assistance free of charge to the manufacturer in rendering services.

In the case of a warranty claim, the manufacturer shall provide replacement parts necessary for servicing free of charge.

General terms and conditions of service

IV. Service visit by the manufacturer

Services rendered on site by an employee of the manufacturer must be agreed in advance.

If the main reason for the service visit is not the fault of the manufacturer, any costs incurred shall be charged to the customer after the service visit and must be paid by the customer in full within the agreed payment term.

V. Liability

The manufacturer shall assume liability in accordance with the currently applicable statutory regulations. All our products are packaged in such a way that the individually packed goods (pallets) can be shipped.

We wish to point out that our packaging is not suitable for individual shipments via parcel post. The manufacturer shall accept no liability for damages incurred as a result of improper packaging in an individual shipment.

VI. Manufacturer's warranty

The manufacturer's warranty shall apply only if installation, operation and maintenance have been carried out in full accordance with the manufacturer's specifications in the assembly instructions and instructions for use.

- The warranty period shall commence from the date on which proof of purchase is provided and shall be limited, in all cases, to 24 months.
- Warranty services shall be performed only if proof of purchase of the equipment can be presented.
- Any and all warranty claims shall become void if modifications are made to the equipment without the manufacturer's express consent.
- Any warranty claim shall likewise become void in the case of defects that arise due to repairs or interventions made by unauthorised persons or due to improper use.
- In the case of warranty claims, the serial and article numbers must be provided, together with the unit designation and a meaningful description of the fault.
- This warranty shall cover defective equipment parts, with the exception of normal wear parts. Wear parts shall include, for example, light sources, glass elements, tubular heating elements and sauna heater stones.
- Only original replacement parts may be used within the warranty period.

- Service visits made by third parties shall require a written order issued by our service department.
- The equipment in question shall be sent to our service department by the customer at the customer's own expense.
- Electrical assembly and installation work, including service visits and parts replacements, shall be carried out at the customer's expense; costs shall not be borne by the manufacturer.

Complaints in respect of our products shall be reported to the responsible distributor and shall be handled exclusively by said distributor.

The manufacturer's General Terms and Conditions of Business, in the version available at www.eos-sauna.com/agb, shall apply in addition to the foregoing terms and conditions of service.

9

Disposal



Electrical devices that are no longer needed must be recycled at a recycling station as per EU guideline 2012/19/EU or as per the Electrical and Electronic Equipment Act (ElektroG). Observe local provisions, laws, regulations, standards and directives when disposing of the unit.



Do not dispose of the unit with household waste.

Packaging

Relay Box for Infrared Cabins packaging can be completely separated for disposal and recycled. The following materials are used in the packaging:

- Used paper, cardboard
- Plastic foil
- Foam material

Electronic waste

Electronic waste must be disposed of at the designated local collection point for electronic waste.

Service address

EOS Saunatechnik GmbH
Schneiderstriesch 1
35759 Driedorf, Germany
Tel. +49 2775 82-0
Fax +49 2775 82-431
Web www.eos-sauna.com

Store this address with the Installation Instructions in a safe place.
Please always provide us with nameplate data, such as model, item number and serial number so we can provide fast and efficient support.

Date of sale

Stamp/retailer signature: